





In this training session, YOU'LL LEARN:









1. Separate the stock from the action

2. Unscrew the factory installed sling swivel stud





## 3. Insert the NeoPod adapter and tighten the supplied M4 screw









## 4. Make sure it looks like this before you reassemble the gun













